

2. PAL DLW Option, Spare Parts and PM Kit

2.1. Spare Parts Order Information for PAL DLW-2 Option

note

Please not that this section of Spare Parts is intended for the PAL DLW-2 Option only. The Spare Parts for the previous version, PAL DLW Option, are listed below under point 2.2.

The upgrade path from 'DLW' to 'DLW-2' is described under point 4.

Part No.:	Description	Illustration	
DLW Pump Modu	DLW Pump Module		
PAL DLWPump	PAL DLW Pump Kit (single module); incl. electrical connections; 24V.	(a) (a) (a)	
PAL DilAspKit	Aspiration Tube Kit, consisting of: 1 pc. Tube PFA 1 pc. Glass Filer, 40 µm pore size 1 pc. Plug with feed through hole.		
Cbl R4LX-1300	Cable for PAL-xt Wash Station round connector, length 130 cm		
PAL DLWPCB	PAL DLW Pump Control Module PCB Kit	<u> </u>	
PAL TubeDLW	PAL DLW Wash Station Tubing Kit, Consisting of: Tubing set, wire supports and connections.		

Table 1. Spare Parts PAL DLW-2 Option.



Part No.:	Description	Illustration
DLW Wash Station		
PAL DLWWash	PAL DLW Wash Station Block, complete assembly (incl. centering plate).	
PAL DLW Insert	PAL DLW Wash Station Insert Kit, consisting of: 2 pcs Inserts 1 pc. Waste Connector 5 pcs. Dummy Plugs	
PAL TubeWaste	Tube Waste for Wash Station, length 2 m.	

Table 1 (cont'd.). Spare Parts PAL DLW-2 Option.



Part No.:	Description	Illustration
DLW Syringe		
SyrC DLW100-R	CTC Syringe for PAL DLW Option, 100 µL gastight; Ø7.7 mm; Scale Length 60 mm; Thread ¼-28 UNF. Removable needle not included.	
PLG DLW 100	Replacement Plunger for Syringe SYRC DLW-R.; pkg of 10.	
PAL DLWPIg	PAL DLW Plunger Holder	
DLW Syringe Hol	der Assembly	1
PAL DLW-2Holder	PAL DLW-2 Syringe Holder Assembly; complete Assembly with Holding Loop (stainless steel) and 100 µL Syringe installed.	
PAL DLW-2Holder- FEP	PAL DLW-2 Syringe Holder Assembly; complete Assembly with Holding Loop (FEP) and 100 µL Syringe installed.	
PAL DLW-2Loop	Kit PAL DLW-2 Holding Loop with Needle, Adapter mounted, including Retaining Nut. Holding Loop: stainless steel.	
PAL DLWLoopKit	Kit PAL DLW-2 Holding Loop with Needle Adapter mounted, PAL DLW Needle incl. Retaining Nut and Flow Diverter. Holding Loop: FEP.	——————————————————————————————————————
PAL DLW Manifold	PAL DLW Manifold Kit, complete, assembled.	
PAL DLWAct	PAL DLW Actuator/Solenoid Kit; incl. screws, without cable.	

Table 1 (cont'd.). Spare Parts PAL DLW-2 Option.



Part No.:	Description	Illustration
PAL DLW-2ActPCB	PAL DLW-2 Actuator Control PCB Kit; incl. cable and screw set.	
PAL DLW Screw	Syringe Holder Fixation Screw, pkg of 1	
PAL DLW NdlTool	PAL DLW Needle Length Guide Tool, pkg of 1.	
PAL DLW-2NHA	PAL DLW-2 Needle Holder Kit	

 Table 1. Spare Parts PAL DLW-2 Option.



2.2. Spare Part Order Information for PAL DLW Option

note

Please note that this section of Spare Parts is specific to the PAL DLW Option.
The listing below shows only the spare parts which are specific to the
'DLW Option'. The other parts are either identical to the 'DLW-2 Option Spare Parts'
or are backwards compatible.

The upgrade path from 'DLW' to 'DLW-2' is described under point 4.

Part No.:	Description	Illustration
DLW Syringe		
PAL DLWNdI	Needle Kit for PAL DLW Option, Gauge 22 PST 3, length 51 mm (3 pcs. per pack); incl. Needle Retaining Nut, Spring Washer and PTFE Seals.	
PAL DLWNdI-C	Needle Kit for PAL DLW Option, Gauge 22 PST 3, length 51 mm Needle coated with inorganic glass layer for inertness. (3 pcs. per pack); incl. Needle Retaining Nut, Spring Washer and PTFE Seals.	
DLW Syringe Hold	er Assembly	
PAL DLW Holder	PAL DLW Syringe Holder Assembly; complete Assembly with Holding Loop (FEP) and 100 µL Syringe installed. 'DLW' version not available as single spare part anymore. Select 'PAL DLW-2Holder-FEP'.	1 2
PAL DLW-2Holder- FEP	PAL DLW-2 Syringe Holder Assembly; complete Assembly with Holding Loop (FEP) and 100 µL Syringe installed. (Replacement Kit for 'PALDLW Holder.)	

Table 2 (contd.). Spare Parts PAL DLW Option.



Part No.:	Description	Illustration
PAL DLWLoop	Kit PAL DLW Holding Loop with Needle, Adapter mounted.	
PAL DLWLoopKit	Kit PAL DLW-2 Holding Loop with Needle Adapter mounted, PAL DLW Needle incl. Retaining Nut and Flow Diverter. Loop: FEP.	_
PAL DLWFlwDiv	PAL DLW Flow Diverter Pkg of 1.	
PAL DLWActPCB	PAL DLW Actuator Control PCB Kit; incl. cable and screw set. 'DLW' version not available as single spare part anymore. The 'DLW-2' version is not backwards compatible. Select 'Upgrade Holder', PNo.: PAL DLW-2UpgrdKit See point 3.4 'Upgrade Path' below.	
PAL DLWNHA	PAL DLW Needle Holder Kit 'DLW' version not available as single spare part anymore. The 'DLW-2' version is not backwards compatible. Select 'Upgrade Holder', PNo.: PAL DLW-2UpgrdKit See point 3.4 'Upgrade Path' below.	

 Table 2. Spare Parts PAL DLW Option.